

COS2

Mounting & Wiring

Installation Instructions

For use with the Sage central battery system

A) MOUNTING METHODS

RECESSED CEILING MOUNT

Set the housing into the drywall or drop-thru ceiling opening, support it from the structure above, bring the low voltage run to the housing and fit the extruded aluminum trim assembly; the trim detaches for service.

WALL MOUNT (WM, SINGLE FACE)

Mount the wall-mount sign over the J-box per the published wall-mount dimensions and route the low voltage run through the housing.

B) WIRING & SYSTEM TEST

1. Turn off the central battery branch circuit before installation. All wiring per NEC and local code; the low voltage run is Class 2.
2. Connect the run conductors from the Sage central battery to the sign, observing polarity per the circuit layout and the Sage central battery installation guide. There is no AC connection and no battery at the sign; signs ordered with the 48 or 60 option take 48 or 60 VDC as ordered.
3. Fit the trim assembly, energize the central battery circuit and verify that the sign is lit in normal service and in emergency transfer.
4. Inspection: check the panel, the legend and the trim seating as local practice requires.

SAVE THESE INSTRUCTIONS

“Engineered for the spaces it protects.”