

LUN

Mounting & Wiring

Installation Instructions

Surface or covered ceiling mount · 120 VAC · triac dimming

A) MOUNTING METHODS

SURFACE OR COVERED CEILING MOUNT

Mount the luminaire to the outlet box, keeping the housing flat to the ceiling; the published data gives no box pattern, so confirm the mounting detail with Sage before rough-in.

COLOR TEMPERATURE

Set the selector switch to 2700, 3000, 3500, 4000 or 5000 K before closing the housing; the factory default is 4000 K.

B) WIRING & SYSTEM TEST

1. Turn off the branch circuit before installation. All wiring per NEC and local code.
2. Connect the 120 VAC supply to the luminaire leads; where dimming is used, wire a compatible triac dimmer from the list on the suggested specification.
3. Energize and verify output and dimming.
4. Inspection: check the diffuser and the fasteners as local practice requires.

SAVE THESE INSTRUCTIONS

“Engineered for the spaces it protects.”