

NEX

Mounting & Wiring

Installation Instructions

Top, end or wall mount · 120/277 VAC

A) MOUNTING METHODS

TOP / END MOUNT

Snap the EZ-snap mounting canopy to the unit's top or end, mount the canopy over the J-box and route the supply through it.

WALL MOUNT

Open the knockout in the universal back plate that matches the supply entry, fix the plate to the box and seat the unit; aim the two lamp heads at the path of egress and snap out the chevron indicators the egress direction requires.

B) WIRING & SYSTEM TEST

1. Turn off the branch circuit before installation. All wiring per NEC and local code.
2. Connect the 120 or 277 VAC supply to the unit leads.
3. Energize, confirm the charge-rate and power-on indicator, and test the transfer with the push-to-test switch.
4. Inspection and testing per NFPA 101 and the AHJ; units with self-diagnostics run the monthly, biannual and annual self-tests.

SAVE THESE INSTRUCTIONS

“Engineered for the spaces it protects.”