

QTZ

Mounting & Wiring

Installation Instructions

Recessed ceiling or wall mount · 120/277 VAC

A) MOUNTING METHODS**RECESSED CEILING MOUNT**

Set the housing into the drywall or drop ceiling opening on the included bar hangers, support it from the structure, bring the supply to the housing and fit the trim assembly; the trim detaches from below for service.

WALL MOUNT (WM)

Mount the wall-mount sign per the published wall-mount dimensions; apply the chevron appliques with the guide template for the egress direction.

B) WIRING & SYSTEM TEST

1. Turn off the branch circuit before installation. All wiring per NEC and local code.
2. Connect the 120 or 277 VAC supply to the sign leads; dual circuit signs take both supplies as marked.
3. Energize; on battery backup signs confirm the charge-rate and power-on indicator and test the transfer with the push-to-test switch.
4. Inspection and testing per NFPA 101 and the AHJ; self-diagnostic signs run the monthly, biannual and annual self-tests.

SAVE THESE INSTRUCTIONS*“Engineered for the spaces it protects.”*