

SPA

Mounting & Wiring

Installation Instructions

½" NPT mounting · 120–277 VAC

A) MOUNTING METHODS

NPT MOUNT

Mount the luminaire on a ½" NPT arm, knuckle or fitting at one of the two threaded openings, bring the supply through the fitting and set the housing angle, up to 90 degrees.

SENSOR

Where a sensor is fitted (ordered separately), set it with the remote control.

B) WIRING & SYSTEM TEST

1. Turn off the branch circuit before installation. All wiring per NEC and local code.
2. Connect the 120–277 VAC supply to the driver leads; connect the 0–10 VDC dimming leads to the control where dimming is used, observing polarity.
3. Sage Relay option: the relay is factory installed in the luminaire; connect it to the Sage central battery low voltage run per the Sage Relay installation guide.
4. Energize and verify output and dimming; where the Sage Relay is fitted, verify emergency operation per the Sage Relay installation guide.
5. Inspection: check the mounting fitting and the lens as local practice requires.

SAVE THESE INSTRUCTIONS

“Engineered for the spaces it protects.”