

# LUM

Universal Back, End or Top Mount

## Installation Instructions

Self-luminous — no electrical connections

### A) UNIVERSAL BACK, END OR TOP MOUNT — SINGLE & DOUBLE FACE SIGNS

#### BACK MOUNT

Select arrows as required by removing the arrow insert(s) in the stencil face sheet legend. Remove the plastic protector from the window; discard the angle bracket. ENSURE THE MOUNTING SURFACE IS FLAT WITH NO RAISED AREAS THAT MAY PENETRATE THE SIGN OR CAUSE BENDING. Use the sign to mark the mounting points, and mount the sign in position using maximum size 8 screws — up to six screws may be used (mounting screws supplied by installer).

#### LEGEND & WINDOW REPLACEMENT

Replace the legend and window: locate the tabs on the edges of the legend face into the slots of the housing, followed by the outer window, which snaps into the housing by inserting its tabs — the window snaps into the housing by locating tabs at six points. Place into position by locating the two bottom tabs, bend the window outwards slightly at the sides to insert the side tabs, then insert the two tabs along the top edge with a ¼" screwdriver, twisting to insert the tabs. To remove the window, insert a flat screwdriver into the slots provided and twist to release the tabs at the two points on the top edge, then flex the window to remove.

#### TOP OR END MOUNT — UNIVERSAL BRACKET

Select the open holes (not the tapped holes), place the bracket in the mount position and mark the screw anchor locations on the ceiling or wall surface. Install the screw anchors, and install the bracket. Attach the sign to the bracket using the two #8-32 Allen-Head screws with lock washers provided.

*“Engineered for the spaces it protects.”*

# LUM

Canopy, Top or End Mount

## Installation Instructions

Model LUM

### B) CANOPY, TOP, OR END MOUNT

1. Assemble the canopy plate to the housing using 2 # 8-32 × ½" screws.
2. If mounting direct to a wall or ceiling, use the canopy plate holes to mark the screw anchor positions, drill and insert anchors. Mount the sign assembly to the selected location using the screws supplied — #8-32 × 1" screws: 2 supplied (single face) · 2 required (double face) — or to a J-Box and spider plate if required (J-Box and spider plate supplied by installer).
3. Per the published exploded diagrams, the #8-32 × 1" screws drive to the surface or box; the J-Box is optional — when used, the spider plate mounts over the box to receive the canopy plate and sign assembly.

**SAVE THESE INSTRUCTIONS**

*"Engineered for the spaces it protects."*