

PIN

Mounting & Wiring

Installation Instructions

Surface mount · 120–277 VAC

A) MOUNTING METHODS

SURFACE MOUNT

Fasten the housing to the wall or ceiling of the stairwell with anchors rated for the fixture weight (3.75 to 8 lb), level, with the supply entering the housing; the published data gives no mounting pattern, so confirm it with Sage before rough-in.

SENSOR

Where the occupancy dimming sensor is fitted (ODS), aim it to cover the flights above and below and set it with the remote control.

B) WIRING & SYSTEM TEST

1. Turn off the branch circuit before installation. All wiring per NEC and local code.
2. Connect the 120–277 VAC supply to the driver leads; connect the 0–10 VDC dimming leads to the control where dimming is used, observing polarity.
3. Sage Relay option: the relay is factory installed in the luminaire; connect it to the Sage central battery low voltage run per the Sage Relay installation guide.
4. Energize and verify output and dimming; where the Sage Relay is fitted, verify emergency operation per the Sage Relay installation guide.
5. Inspection: check the lenses and the fasteners as local practice requires.

SAVE THESE INSTRUCTIONS

“Engineered for the spaces it protects.”